

Instructions for ToolScoat Door Mounting

- 1) For best results, check the tower for squareness with a carpenter's square while bolts are being tightened. Loosen and re-tighten the hardware as needed.
- 2) Prior to mounting, carefully peel the protective coverings from a polycarbonate door pane. With the locks in the locked position, lay a door face-down on a non-abrasive surface and carefully slide the pane under the guide rails in the door. As you slide it in, you will need to bend the pane away from the edge of the door so as to avoid scratches. Once the pane is fully inserted, remove the backing from the affixed double-face tape and press the pane firmly onto the tape. Repeat for remaining door(s).
- 3) If doors are going on both sides of a cart, do one side at a time. Remove all existing mounting hardware from the face of the cart where the doors will be mounted.
- 4) Place washers between the hinges and the side panels to fill the gaps at the middle shelf and where the new hardware goes. Do not tighten yet.
- 5) Align the doors vertically. Align the cart with a carpenter's square.
- 6) While maintaining squareness, tighten all nuts and bolts.

